



Walnut Industries Europe B.V.
Rembrandtweg 257
2981 CZ Ridderkerk
The Netherlands
Tel: +31.180.490.120
Fax: +31.180.490.125
Email: info@ty-gard.eu
sales@ty-gard.eu

Demo

This live demonstration will show just how easy it is to use TY-GARD 2000, the industrial strength cargo restraint system.

Combined with TY-PATCH 2000 and our handy toolkit, TY-GARD 2000 is the economical and **easy-to-install** load securement solution to prevent freight damage, minimize injury and liability, and reduce shipping costs. Protect your valuable products in transit!

1. Cut two lengths of TY-GARD 2000 for each band required and one 5 ft length of TY-PATCH 2000. Then peel the backing sheet from the TY-GARD 2000 and apply the adhesive strip to the wall in the predetermined position. We suggest that the adhesive start at least 1 ft (30 cm) back from the face of the load. TY-GARD 2000 should be parallel to the floor. Using the bonding roller press firmly to the wall.
2. Follow the same procedure on the opposite wall and bond to the contour of corrugations in Containers. Then finish loading materials in to the Container. Please contact your TY-GARD 2000 representative to help you determine the number of bands required for your load (HAZMAT and Railroad loads require additional bands).
3. Pull the TY-GARD 2000 strips across the face of the load overlapping ends at least 1 ft (15 cm). Cut excess if necessary.
4. Next insert the clothespin through the overlapping portions. Place the small wrench on first with the long wrench on top, position the handle flush against load. Both wrenches in matching "off" position. Use the small wrench to tension TY-GARD 2000. Cut excess if necessary.
5. Remove backing and place TY-PATCH 2000 across barrier using the bonding roller to assure proper adhesion. Use tape to attach TY-GARD 2000 to the cargo. For easy disposal by receiver, simply cut TY-GARD 2000, remove cargo and peel towards the nose of the container.

